



Remote Status Light and Combination Displays

Monitor reefer status and fuel level from the driver's seat.





Stay on top of your reefer's status

with just a glance in the rear view

Remote Status Light Displays

- Helps avoid expensive out-of-fuel shutdowns
- For use with all Thermo King SB trailer units with SR-2/SR-3 controllers (Status Only Display works with TGVI or newer controllers)
- Solid state design - sealed against elements with no bulbs to replace
- Feature high-visibility LED lights and an auto-dimming feature for night driving
- Available in 4 configurations

Fleet Facts

Running out of fuel is a common and expensive problem that is preventable with the Fuel Combo display.

Preventable expenses include:

- High cost of unscheduled service call-outs for priming
- Risk of battery, alternator and starter damage due to repeated restart attempts without fuel

Triple Combo Display

Light Sensor

Lights automatically dim for better night visibility.

Functioning Properly

Illuminates the white "T" when unit is functioning properly with no alarm codes

Check Alarm Code


Amber "K" is illuminated when the unit has a "check alarm code" but is still functioning. Unit should be checked at earliest convenience.

Shutdown Alarm

Bottom row of amber and white LEDs are illuminated when unit has shutdown alarm. Requires immediate attention.

Temperature Reading


Shows temperature or "dF" when zone is defrosting. Temp readout can be set for direct or mirror viewing. Reads out in degrees celsius or fahrenheit, depending on the SR-2/SR-3 controller settings.



Compartment Indicators

LEDs indicate which multi-temp compartment temperature reading refers to (up to 3).


mirror!



Fuel Level


LED display shows fuel level. As fuel is consumed, white LEDs go out. When fuel level drops below 25% only amber LEDs remain illuminated. When fuel drops below 15%, one amber LED and the amber "K" are lit for check alarm status.

Also Available in Four Additional Configurations:



Status Only Display

Provides on-road visibility to basic functions, including check alarm codes and shutdown alarms.




Fuel Combo Display

Offers all features of Status Only display, plus fuel level display and low fuel, check alarm and shutdown alarms.



Temperature Only Display

Displays temperature and can be set for direct or mirror viewing. Utilizes robust air temperature sensor and can be used with all controllers.



Fuel Only Display

Provides on-road visibility of fuel level to help prevent costly out-of-fuel shutdowns.

Ordering Information

Display	Status & Alarms	Fuel Level	Temperature	Fuel Tank Gauge Kit	Part # (Corner Mount)	Part # (Flush Mount)
Status Only	✓				40-980	40-981
Fuel Combo	✓	✓			40-1068	40-1067
Fuel Combo	✓	✓		✓	40-1070	40-1071
Triple Combo	✓	✓	✓		40-1110	40-1112
Triple Combo	✓	✓	✓	✓	40-1109	
Temp. Only (°F)			✓		40-1119	
Temp. Only (°C)			✓		40-1120	
Fuel Only		✓		✓	40-1165	40-1160

All displays are corner-mount except where noted. 1-year parts warranty.



Ingersoll Rand's Climate Solutions sector delivers energy-efficient HVACR solutions for customers globally. Its world class brands include Thermo King, the leader in transport temperature control and Trane, a provider of energy efficient heating, ventilating and air conditioning systems, building and contracting services, parts support and advanced controls for commercial buildings and homes.

TK 53935-8-PL (2/12)

©2012 Ingersoll-Rand, plc
Printed in U.S.A. on Recycled Paper